

TRAXX RAMPS

ENGINEERED FLOORING RAMPS

LevelUp
BIRCH PLYWOOD RAMPS

AND

CarpetShims
COMPOSITE BOARD RAMPS

INSTALLATION of 90-DEGREE ANGLE RAMPS

Installing Ramps Up To 1/2" thick:

Determine the hard surface width and add 1/2" to that length. On the rough side of the carpet ramp, using a carpet knife, score the ramp three or four times at the needed length and snap it. Place the ramp next to the hard surface with the smooth side up and the high side toward the hard surface, leaving a *1/4" gap between the ramp and the hard surface. Space your ramp, allowing 1/4" over on each side. Nail at least 5 ring shank nails per 32" of carpet ramp, centered and evenly spaced. Place a Composite Board Side Return at each side of the carpet ramp and nail all corners securely to the floor. Determine your return length and repeat the ramp installation procedure. Install the tack strip on top of the carpet ramp maintaining the *1/4" gap. Install your pad and carpet, tucking the carpet into the 1/4" gap. It is that simple!



Composite Board Side Returns used to make an outside corner

*Regarding the 1/4" gap: When extremely thick or thin carpet is being installed, adjust the gap accordingly. Also refer to hard surface manufacturer's recommendations.

Installing Ramps Over 1/2" thick:

All instructions above apply with the exception of cutting the 5/8" Extension and the 1" Super Shim. A saw will be required to cut these two ramps.

All Traxx Ramps may also be installed using a good construction adhesive.