

# TRAXX RAMPS

ENGINEERED FLOORING RAMPS

**LevelUp**  
BIRCH PLYWOOD RAMPS

AND

**CarpetShims**  
COMPOSITE BOARD RAMPS

## STANDARD INSTALLATION INSTRUCTIONS

### Installing Ramps Up To 1/2" thick:

Determine the width of the opening. On the rough side of the ramp, using a carpet knife, score the ramp three or four times at the needed length and snap it. Place the ramp in the opening with the smooth side up and the high side toward the hard surface, leaving a \*1/4" gap between the ramp and the hard surface. Centered and evenly spaced, nail at least 5 ring shank nails per 32" of carpet ramp. Place a Composite Board Side Return at each side of the carpet ramp and nail all corners securely to the floor. Install the tack strip on top of the carpet ramp maintaining the \*1/4" gap. Install your pad and carpet, tucking the carpet into the 1/4" gap. It is that simple!



**Ramp installed in 32" doorway with Composite Board Side Returns**

\*Regarding the 1/4" gap: When extremely thick or thin carpet is being installed, adjust the gap accordingly. Also refer to hard surface manufacturer's recommendations.

### Installing Ramps Over 1/2" thick:

All instructions above apply with the exception of cutting the 5/8" Extension and the 1" Super Shim. A saw will be required to cut these products.

**All Traxx Ramps may also be installed using a good construction adhesive.**