



September, 2016

Bulletin: TraxxShield100 Installed Over Wood Subfloors

This bulletin serves as approval to install TraxxShield100 Rolled Moisture Barrier over Wood Subfloors, inclusive of Plywood, OSB, and Particleboard. TraxxShield100 is suitable to bond to these wood substrates when TraxxShield Primer is first applied to the wood surface. Please only use TraxxShield Primer to ensure good adhesion.

The TraxxShield100 Rolled Moisture Barrier surface is flat and uniform and will provide a suitable membrane for floorcovering installation. However, TRAXX Corporation is not responsible for any wood subfloor irregularities or seam lines that may telegraph through to the surface.

Also, TraxxShield100 would not be approved for a wood subfloor installed directly over concrete.